



- 1) remove the 0 ohm resistors circled in red.
- 2) solder wire 1 (red) from the connector to point 1 (see yellow arrows). Then wire 2 to point 2, wire 3 to point 3, and so on...
- 3) check that everything works.
- 4) if so, drill the 6 holes.
- 5) put the board in place, tighten the jacks with the nuts and...
You're done !